



INCOMING POWER

MOTOR

OPTIONAL LOOP DETECTOR BOARD

NOTE: XFMR WIRE COLORS MAY VARY

NOT USED

NOTE:
120V BRAKE SOLENOID
CONNECTS TO WHITE
AND BLUE IN THE MOTOR

**NOTE: MONITORED SAFETYS ARE REQUIRED
FOR MOMENTARY CONTACT TO OPEN & CLOSE**

REQUIRED
**SOFTWARE ENABLED
SECOND MONITORED
SAFETY DEVICES**

**ALL SAFETIES
ACCEPT PULSE AND
10K MONITORED DEVICES**

NOTE: SWAP ORANGE AND RED ON 208 /240
ON XFMR IF BOARD FAILS TO POWER

Title: 8601 DB		V.E. Power Door cannot open file CAUsers\mat\Desktop\PM 140 Emjay Blvd.LOGO.PNG	
Revision: 0	Voltage: 120/240 1Ø	Brentwood NY, 11717 USA	
Drawn by: JD	Date: 5/3/2019		
© Copyright PowerMaster 2018 No portion of this diagram may be reproduced without written permission of the manufacturer.			